# SILICON CHIP

50A Battery
Charger Controller

Power ⊕ | ⊕ Charge | **Off** : Battery disconnected
Flashing: Charging
Constantly lit: Charged

Panel when S1 used

SILICON CHIP

50A Battery Charger
Adaptor

12V

⊕

24V

Power ⊕ | ⊕ Charge | **Off** : Battery disconnected
Flashing: Charging
Constantly lit: Charged